



manual release

WN 200-26




limit switch "manual release engaged"

WN 200-24




proximity switch "brake closed"

WN 200-27



proximity switch "brake released"

WN 200-25



proximity switch "pad wear"